



Set self drilling drywall screws through mud flange and into ceiling blocking, complete ceiling as required. (This step is optional.)

CEILING CLIP (EACH SIDE)


See note below for proper length of conduit. Failure to do so will make future maintenance of ballast or wiring difficult.

Wire power supply to terminal block an put back into enclosure, replace thumb screws and secure unit in place.

Wire power supplies as required using approved wiring methods and hardware.

Insert gimbal assembly in box repeating steps above. Replace thumb screw.


Gimbal assembly can be mounted in two positions (high and low) by flipping it over.



SELF DRILLING DRYWALL SCREW

ADJUSTMENT SCREW

PHILIPS SCREWDRIVER



OPTIONAL BUTTERFLY BRACKETS
HIPPED SEPARATELY SEE SEPARATE
HEET FOR MOUNTING INSTRUCTIONS

INSTALLATION INFORMATION:
DO NOT INSTALL INSULATION WITHIN 3" (76mm)
OF ANY PART OF THIS FIXTURE, DO NOT BLOCK
YENT HOLES ON FIXTURE, MAXIMUM AMBIENT
TEMPERATURE NOT TO EXCEED 35°C.

corp.